





Fallen cargo scattered on the road or trail is one of a driver's worst nightmares.

Two tailor-made nets to keep cargo in place are now available for the Stryker Interim Combat Vehicle. Both nets are easily adjustable for a snug fit. Each black nylon net is held in place with snap hooks.

A three-position molded nylon clamp locks a clinching rope, which goes around the entire net. Each net comes with a storage bag and attachment instructions.








Make a note of these NSNs until they're added to the vehicle's -10 TM.



All loads over fifty pounds must be strapped to cargo tie-downs in the back of the vehicle, and the cargo shelf up front. To keep cargo in place, use cargo net, NSN 3940-01-477-6758, for the rear and cargo net, NSN 3940-01-477-7095, for the front.

Front cargo net, NSN 3940-01-477-7095

Make sure you inspect the M-GATOR after an air-drop operation. Eyeball the vehicle for fluid leaks and any loose or damaged components.




Only the driver and passenger can occupy the vehicle in the front seats. Do not pick up any hitchhikers.



Make sure you wear a helmet and eye protection (goggles).



Ammunition must be on a pallet and strapped down in the vehicle's rear cargo area.



PS 612

47

**NOV 03**